

SMB30SC	SMB30SK	SMB30SUS	SMB30UR		
All measurements in mm	All measurements in mm	All measurements in mm	All measurements in mm		
<p>Hole center spacing: A = 50.8 Hole size: A = \varnothing 7, B = \varnothing 30</p>	<p>Hole center spacing: A = 50.8 Hole size: A = \varnothing 7, B = \varnothing 18</p>	<p>Hole center spacing: A = 50.8, B = 24.1 Hole size: A = \varnothing 7, B = \varnothing 7.6</p>	<p>Hole center spacing: A to B = 31.8, B to C = 19, A to C = 50.8, D = 50.8 Hole size: A, B, C = 6.9 x 32, D = 73 x 6.9</p>		
<ul style="list-style-type: none"> • Swivel bracket with 30 mm mounting hole for sensor • Black reinforced thermoplastic polyester • Stainless steel mounting and swivel locking hardware included 	<ul style="list-style-type: none"> • Flat-mount swivel bracket with extended range of motion • Black reinforced thermoplastic polyester and 316 stainless steel • Stainless steel swivel locking hardware included 	<ul style="list-style-type: none"> • Side-mount swivel bracket with extended range of motion • Black reinforced thermoplastic polyester • Stainless steel swivel locking hardware included 	<ul style="list-style-type: none"> • 2-piece universal swivel bracket for limit-switch style sensors • 300 series stainless steel • Stainless steel swivel locking hardware included 		
Barrel Mount	Barrel Mount	Side Mount	Side Mount		
Used with	Used with	Used with	Used with		
QS30 SM30/SMI30 S30 T30	T30U EZ-LIGHT T30 PICO-GUARD Point	QS18 MINI-BEAM S18/M18/T18 T18U S18U	QS18U Q45UR S18C2 Q45UR M18C2 EZ-LIGHT T18 EZ-LIGHT M18	QS18 MINI-BEAM QM42/QMT42 QS18U	Q45 OMNI-BEAM Q45U Q45UR
Base Mount	Base Mount				
Used with	Used with				
Q40 Q45 OMNI-BEAM OTB/LTB VTB STB QT50U	Q45U Q45UR QT50R K50 EZ-LIGHT K50L EZ-LIGHT TL50 EZ-LIGHT CL50 WL50 Work Lights	Q25			
Base Mount	Base Mount				
Used with	Used with				
Q40 Q45 OMNI-BEAM OTB/LTB VTB STB QT50U	Q45U Q45UR QT50R K50 EZ-LIGHT K50L EZ-LIGHT TL50 EZ-LIGHT CL50 WL50 Work Lights	Q25			
Base Mount	Base Mount				
Used with	Used with				
Q40 Q45 OMNI-BEAM OTB/LTB VTB STB QT50U	Q45U Q45UR QT50R K50 EZ-LIGHT K50L EZ-LIGHT TL50 EZ-LIGHT CL50 WL50 Work Lights	Q25			
Base Mount	Base Mount				
Used with	Used with				
Q40 Q45 OMNI-BEAM OTB/LTB VTB STB QT50U	Q45U Q45UR QT50R K50 EZ-LIGHT K50L EZ-LIGHT TL50 EZ-LIGHT CL50 WL50 Work Lights	Q25			
Base Mount	Base Mount				
Used with	Used with				
Q40 Q45 OMNI-BEAM OTB/LTB VTB STB QT50U	Q45U Q45UR QT50R K50 EZ-LIGHT K50L EZ-LIGHT TL50 EZ-LIGHT CL50 WL50 Work Lights	Q25			


 More on next page