

SMB312B	SMB312PD	SMB312S	SMB4050YL
<p>All measurements in mm</p>	<p>All measurements in mm</p>	<p>All measurements in mm</p>	<p>All measurements in mm</p>
<p>Hole center spacing: A to B = 17.3, B to C = 17.7, A to C = 35 Hole size: A = \varnothing 6.9, B = 4.3 x 10.5, C = 3.1 x 15.2</p>	<p>Hole center spacing: A to B = 24.2 Hole size: A = \varnothing 4.6, B = 17 x 4.6, C = \varnothing 18.5</p>	<p>Hole center spacing: A = 20.3, B to C = 5.1 Hole size: A = 4.3 x 7.5, B = \varnothing 3, C = 3 x 15.3</p>	<p>A = \varnothing 15.3</p>
<ul style="list-style-type: none"> Right-angle Stainless steel base mounting bracket Includes mounting foot 	<ul style="list-style-type: none"> Right-angle mounting bracket with a curved slot for versatile orientation 12-ga. stainless steel, 18 mm sensor mounting hole Clearance for M4 (#8) hardware <p>NOTE: Not for use with plastic fiber optic sensors</p>	<ul style="list-style-type: none"> Stainless steel 2-axis side-mounting bracket 	<ul style="list-style-type: none"> Heavy-duty die-cast bracket for industrial protection Replaceable window for use with some sensor models M18 vertical mounting option Nut and lock washer included
Base Mount	Barrel Mount	Side Mount	Base Mount
<p>Used with</p>	<p>Used with</p>	<p>Used with</p>	<p>Used with</p>
MINI-BEAM	<p>QS18 MINI-BEAM S18 M18 T18 TM18 S18U</p>	<p>QS18U Q45UR S18C2 Q45UR M18C2 T18U EZ-LIGHT T18 EZ-LIGHT M18</p>	QS18 DC Models (except AF)
	Base Mount		
	<p>Used with</p>		
	Q25		

More on next page