

SMB46A		SMB46L		SMB46S		SMB46U	
All measurements in mm		All measurements in mm		All measurements in mm		All measurements in mm	
Hole center spacing: A to B = 18.5, B = 30.5 Hole size: A = \varnothing 6.6, B = 7.1 x 20.3		Hole center spacing: A = 16 Hole size: A = 16.5 x 18.7		Hole center spacing: A = 16 Hole size: A = 16.5 x 18.7, B = 34 x 10		Hole center spacing: A = 16 Hole size: A = 16.5 x 18.7, B = 34 x 13	
<ul style="list-style-type: none"> • 2-piece 12-ga. stainless steel bracket assembly with precision sensor alignment adjustment • 2 mm hex key included 		<ul style="list-style-type: none"> • Right-angle • L bracket • 14-ga. 316 stainless steel 		<ul style="list-style-type: none"> • Right-angle • S bracket • 14-ga. 316 stainless steel 		<ul style="list-style-type: none"> • Right-angle • U bracket for sensor protection • 14-ga. 316 stainless steel 	
Barrel Mount		Side Mount		Side Mount		Side Mount	
Used with		Used with		Used with		Used with	
QS18 Lasers S18 Laser Emitter QS18U		QS18 MINI-BEAM QS30	PicoDot QM42/QMT42 QS18U	QS18 MINI-BEAM QS30	PicoDot QM42 QS18U	QS18 MINI-BEAM PicoDot	QM42 QS18U
Side Mount							
Used with							
PicoDot							

